







Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Teltitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD, .....

- 1 - B 961531 XX
- 2 - B 960473 XX
- 3 - B 961373 XX
- 4 - B 961374 NU
- 5 - A 861181 NU
- 6 - B 961491 NU
- 7 - A 961625 XX
- 8 - A 964520 NU
- 9 - B 960845 NU




- 1 - B 961531 XX
- 2 - B 960473 XX
- 3 - B 961373 XX
- 4 - B 961374 NU
- 5 - A 861181 NU
- 6 - B 961491 NU
- 7 - B 960486 XX
- 8 - A 961625 XX
- 9 - B 960168 XX
- 10 - A 960944 NU
- 11 - A 962575 NU
- 12 - B 960255 NU
- 13 - A 963449 NU
- 14 - B 960845 NU
- 15 - B 960925 XX



Ideal Standard

EDGE

02.2021 / B565127





















A 7580 ..

A 7579 ..




Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium  
<http://www.idealstandardinternational.com>





P	T	°C	0	1	2	3	4	5
			°C	°C	°C	°C	°C	°C
50°C	15°C	50	49	44	40	35	33	
65°C	15°C	65	63	57	50	44	40	
85°C	15°C	85	83	74	64	56	50	



P	bar	MAX. 10	3	1	Q (1 bar)
T	°C	MAX. 80	65	40	l/min
					16
					8